



- Comments:
1. Membrane to be fully adhered down wall/curb and out a minimum 30 cm (12") onto insulation or deck.
  2. Refer to Detail L-B-101 or 102 if membrane is positioned over gypsum board or another base insulation.
  3. New concrete must be fully cured for 28 days prior to bonding.
- \* Metal Counterflashing is recommended to help prevent insulation movement.



**Flatbond™ Method for Protected Membrane  
Roof System  
Roofing System Detail**

Scale: Not to scale  
Date: August, 2016  
Detail No.: L-B-105