



- Notes:
1. All drain bolts or clamps must be in place to provide compression on Water Cut-Off
 2. Cut membrane so it extends a minimum of 13mm (1/2") from attachment points of the clamping ring.
 3. Cut edge sealant is required on cut edges of Hi-Tuff TPO membrane.
 4. Seam overlap direction to be reversed if main field membrane is Hi-Tuff Fleece-Backed Membrane.



**Drains with Tapered Sumps
greater than 3:12
Roofing System Detail**

**Scale: Not to scale
Date: August, 2016
Detail No.: H-S-323**