

LEXCAN

HI-PRO PVC

Inside Corners

DESCRIPTION & USE

Lexcan Hi-Pro PVC Inside Corners are made of 1.5 mm (60-mil un-reinforced PVC flashing. They are pre-molded and are used for flashing inside corners on a variety of details.

FEATURES & BENEFITS

Flexible – forms easily into out-of-square corners that are not exactly 90 degrees

Aesthetically Pleasing – more professional and consistent appearance than field-fabricated inside corners from un-reinforced flashing

Saves Money – provides substantial labour savings compared to field-fabricating the detail from un-reinforced flashing

TECHNICAL DATA

Typical Properties & Characteristics	
Thickness:	1.5 mm (0.060")
Packaging:	12 per bag
Material:	Un-reinforced PVC
Colour:	White and Grey
LEED Information	
Pre-Consumer Recycled Content:	0%
Post-Consumer Recycled Content:	0%
Solar Reflectance Index (SRI):	White - 111 Grey - 43

CAUTIONS & LIMITATIONS

- Store Lexcan Hi-Pro PVC Inside Corners in a cool, shaded area and cover with light coloured, breathable, waterproof tarpaulins. PVC Inside Corners that have been exposed to the weather, or contaminated with dirt, must be prepared with Lexcan Hi-Pro PVC Membrane Cleaner before hot-air welding.
- Lexcan Hi-Pro PVC Membrane Cleaner is specific to PVC Membrane. Do not use Lexcan Weathered Membrane Cleaner on PVC membrane.



INSTALLATION

1. Position the Hi-Pro PVC Inside Corner into the desired corner. Begin welding at the innermost corner point and work away from the corner.
2. Use the edge of the roller to crease the corner flashing into any membrane step-off to create a proper seal.
3. Once the Inside Corner has completely cooled, using a seam probe, check the welded edges for voids and cold welds. Make any needed repairs.

lexcan.com

LEXCAN SINGLE PLY ROOFING SYSTEMS

Ontario and Western Canada
1 877 792.8308



Quebec and Eastern Canada
1 800 363.2307