

LEXCAN

HI-TUFF TPO

Outside Corners

DESCRIPTION & USE

Lexcan Hi-Tuff TPO Outside Corners are made of 1.5 mm (60-mil) un-reinforced TPO flashing. They are pre-molded and are used for flashing outside corners on a variety of details.

FEATURES & BENEFITS

Pre-formed Design – allows wrapping outside corners that are out-of-square and not exactly 90 degrees

Aesthetically Pleasing – more professional and consistent appearance than field-fabricated outside corners from un-reinforced flashing

Saves Money – provides substantial labour savings compared to field-fabricating the detail from un-reinforced flashing

TECHNICAL DATA

Typical Properties & Characteristics	
Thickness:	1.5 mm (0.060")
Packaging:	12 per bag
Material:	Un-reinforced TPO
Colour:	White and Grey

LEED Information	
Pre-Consumer Recycled Content:	0%
Post-Consumer Recycled Content:	0%
Solar Reflectance Index (SRI):	N/A

CAUTIONS & LIMITATIONS

- Store Lexcan Hi-Tuff TPO Outside Corners in a cool, shaded area and cover with light colored, breathable, waterproof tarpaulins. TPO Outside Corners that have been exposed to the weather, or contaminated with dirt, must be prepared with Lexcan Weathered Membrane Cleaner before hot-air welding.



INSTALLATION

1. Position the Hi-Tuff TPO Outside Corner into the desired corner. Begin welding at the innermost corner point and work away from the corner.
2. Use the edge of the roller to crease the corner flashing into any membrane step-off to create a proper seal.
3. Once the Outside Corner has completely cooled, using a seam probe, check the welded edges for voids and cold welds. Make any needed repairs.